

**PART NUMBER**

# PFR5-4626

**DESCRIPTION**

REAR DIFF REAR BUSH

**INSTALLATION GUIDE****Contents (parts per pack):**

1 x 5-4626A bush      1 x 5-4626B bush      1 x Stainless steel sleeve  
2 x Zinc Plated Washers      1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
  - all safety precautions adhered to;*
  - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove rear diff rear bush from the subframe. Clean any rust and dirt from around the surrounding area of the subframe.
2. Push the new A bush, thicker larger diameter, into the subframe from the centre of the car outwards so the larger diameter end of the bush fits against the diff.
3. Push the new B bush, thinner larger diameter, into the subframe from the left side of the car so the larger diameter is always from the diff.
4. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush.
5. Whilst refitting the diff fit the new washers, one between the bush and diff and the other on the outer bush. Re use the original nut, bolts and washers.

