

# POWERFLEX®

PART NUMBER

**PFF34-602**

DESCRIPTION

**REAR ENGINE MOUNT INSERT**

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x Polyurethane Insert

4 x Nylon Washers

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the rear engine mount from the vehicle.
2. Push the 2 polyurethane inserts into the voiding in the rubber bush.
3. Place the nylon washers over the ends of the outer faces of inserts
4. Refit the mount to the vehicle, ensuring to tension all fasteners to the manufacturers' recommended torque settings.

