

POWERFLEX®

PART NUMBER

PFF60-8027

DESCRIPTION

LOWER TORQUE MOUNT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Aluminium Bracket with Prefitted Bushes and Sleeves

1 x PTFE/Silicone Grease

2 x Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

-all work to be carried out by a licensed technician;

-all safety precautions adhered to;

-wheel alignment to be checked and adjusted as required after any suspension work.

-All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove OEM mount from vehicle.
2. Apply supplied grease liberally to both faces of both bushes.
3. Place a washer on either side of the larger bush ensuring the bores align with the sleeve bores.
4. Fit torque mount to car, ensuring the washers stay in place.
5. Refit all bolts and tighten to manufacturers' recommended torque settings.

